

Installation Guide

COMBINATION PAPER TOWEL & WASTE RECEPTACLE

ML 706 Series

(Refer to Metlam binder or WEB site for all dimensions)

Surface Mount

The below is provided as a guide only; proper building practices and PPE should always be used.

1. It is always good practice to draw an outline of the unit on the wall before drilling or fixing the unit in place to ensure that the unit position will maintain its functionality and does not foul or hinder the operation of any other items.
2. Obtain the required height of the unit from the client or from architectural drawings. Map the position of the unit onto the wall in the required position.
3. Mark the position of the fixing holes in the back of the unit in the required position, ensuring that they are level. Check Twice Drill Once.
4. Drill holes and use the appropriate fixings for the wall; masonry anchors for brick or block work, hollow wall anchors for plaster or villa board.
5. Fix the unit to the wall but only use enough pressure to just hold the unit in place, using a level, check to ensure that the unit is in its correct position and the surface mount surround is positioned correctly, then tighten the fixings to hold the unit firmly in place.

Semi-Recessed

1. Draw an outline of the unit on the wall, ensuring that the unit will maintain its functionality and does not foul or hinder the operation of any other items.
2. Draw inside of this outline the functional box section that will have to be cut from the wall that allows the unit to be recessed, allow approx 5mm on all sides to allow easy fitment of the unit. Check Twice, Cut Once.
3. Before cutting the hole, check to ensure that there are no services within the area to be cut. Cut out the area that allows the unit to be recessed and remove.
4. It will be necessary to box out the cavity to allow for the fixing of the unit through the side fixing holes.
5. Pack out the cavity, ensuring that the packing will allow the unit to sit level and plumb. (It is recommended that the unit not be fixed in a way that the securing screws are supporting the weight of the unit, but is sitting on the cavity boxing)
6. Insert the unit into the cavity and ensure that the semi-recessed surround is in the correct position.
7. Fix off the unit, ensuring that the unit is held firmly in place, Do Not over tighten the fixing screws as this may distort the unit and affect the operability of the unit.

Recessed

As for the Semi-recessed unit, but you do not have to ensure that the surround is in the correct position.

These units should only be installed by a competent tradesperson and Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect installation.