




MATERIAL SPECIFICATION & INSTALLATION GUIDE

PRODUCT ITEM CODE & DESCRIPTION:

ML 663 W ~ ABS - 600ml LIQUID SOAP DISPENSER



MATERIAL SPECIFICATIONS / FEATURES:

ABS body & mounting bracket - White Finish / Pump Type Valve / Clip on Lid / Soap Level Indicator / Mounting Bracket and Fixings included

DIMENSIONS:

Overall ~ 152mm W x 106mm H x 55mm D

INSTALLATION GUIDE:

1. May be subject to Australian Building Code Regulations for height/location fixing and/or subject to placement as per architectural drawings, which in all cases is the responsibility of the installer re compliance.
2. Unit is provided with separate mounting bracket & fixings
3. Remove wall mount bracket, locate height on wall and mark using fixing holes on wall plate, ensuring unit is level and even. Measure/Check Twice ... Drill Once
4. Drill holes and loosely secure bracket to wall surface using appropriate screws/wall-plugs
5. Check level and tighten fasteners, then locate dispenser onto bracket, pushing down to lock into place.

NOTE: The recommended liquid soap (not included) *must* be of an adequate viscosity to ensure correct soap valve function and operational integrity/longevity of the unit.

These units should only be installed by a competent tradesperson and Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect installation.