



MATERIAL SPECIFICATION & INSTALLATION GUIDE

PRODUCT ITEM CODE & DESCRIPTION

ML 780 / 781 Series ~ MEDICINE CABINET/MIRROR



- ML 780 SS** – Recessed (As shown)
- ML 780 SS SM** – Surface Mount (with Surround)
- ML 781 SS** – Recessed with Lockable Tumbler Lock
- ML 781 SS SR** – Semi-Recessed (with Surround) with Lockable Tumbler Lock
- ML 781 SS SM** – Surface Mount (with Surround) with Lockable Tumbler Lock

Cabinet Shelving–

- 5 off 90mmD x 385mmW Shelves (including base), with 4 shelves that can be removed as required for extra storage space for likes of tall bottles etc or, shelves can be inverted to provide a protective lip option.
- Optional Mounting for Door Opening (Left or Right) with twin magnetic catches (ML 780 Series)

Mirror –

- 775mmH x 435mmW x 5mm Vinyl Backed Safety Mirror

Cut-out Dimensions ~ (Semi-Recessed or Recessed models)
410mm W x 735mm H x 90mmD

Mounting Points ~Rear @ 50mm in from Left/Right & 105mm Up/Down from edges / Side (Recessed) @ 60mm in from rear of internal facia & 105mm Up/Down from edges

MATERIAL SPECIFICATION:

#304 Grade Stainless Steel, Exposed Surfaces #3 (Satin) Finish

DIMENSIONS:

Overall ~ 435mm W x 800mm H x 110mm D

Projections: Recessed 5mm / Semi-Recessed 60mm / Surface Mount 115mm

INSTALLATION:

1. May be subject to Australian Building Code Regulations or architectural plans for installation height, which is the responsibility of the installer.
2. Locate height requirement & mark on wall (ensuring no internal services fittings or fixtures are present such as electrical or plumbing - cut out section for Recessed unit & mount battens to internal wall section to secure to) then drill fixing holes using mounting point holes.
3. It is recommended that the unit is installed whereby it clears any other fixtures by at least 200mm and that when fixing, it is secured using appropriate fasteners/anchors into studwork, noggings or suitable substrate support to ensure rigidity and longevity in application
4. Secure to wall surface/cavity with appropriate screws/wall-plugs (to be provided by the installer).
5. Check open/closing mechanism for smoothness and on ML 781 Series, use key/tumbler lock.

These units should only be installed by a competent tradesperson and Metlam Australia takes no responsibility for any damage to walls or fixtures due to incorrect installation.